


SH Baseball Scoreboard Instructions

Turn scoreboard on

- Top left is a black toggle switch to turn on
 - o If it does not cut on – check plug – check switch at field board on pole – get help
- Once on hit enter at the enter to resume screen below
- Hit Clear – New Game – Enter as highlighted on right
- Scoreboard should be ready to work or else get help




Work Scoreboard

- Items used are highlighted in yellow
 - o Runs – Outs – Innings – Ball – Strike – Clear Ball and Strike





- If you accidentally increase innings or runs too high, you can set it manually
 - o Use the below guideline
 - For score – hit enter – home runs +1 – the number of the score – enter again
 - For innings – hit enter – inning + 1 – the number of innings – enter again




Troubleshooting Scoreboard

If the scoreboard will not cut on...


- Make sure it is plugged in first
- Check codes... each scoreboard has same codes except channel is the field number



- At this screen Clear/Alt instead of enter – make sure the code is 005 or else enter hit and hit enter



- Next screen shows the broadcast and channel



- Broadcast is always 1 for all scoreboards – the channel is the FIELD number
- Hit 1 for BCAST – enter and the field number then enter again
- Hit Clear – New Game – Enter... should work
- If scoreboard still is not coming on... send someone to the pole and cut switch off /on